


# OWNER'S MANUAL

## SINGLE CHAMBER BLAST MACHINES ABSC-1440 / 1648 / 2048 / 2452 / 2460

### IMPORTANT WARNING FOR SAFER BLAST CLEANING

1. Use protective equipment: Abrasive-resistant clothing, safety shoes, leather gloves, ear protection, CE-approved air-fed helmet. Air for helmet must be supplied by a breathing air compressor or through a helmet air filter.
2. Check for possible silicosis hazards. Avoid dust.
3. Do not blast with damaged or worn equipment.
4. Point nozzle only at area being cleaned.
5. Use only proper dry and well-screened abrasives specifically intended for blasting.
6. Keep unprotected workers out of the blast area.
7. Before blasting:
  - Check fittings and hose for wear.
  - Safety-wire couplings together.
  - Check helmet filters and air supply.
  - Check pop-up valve for alignment.
  - Test remote controls.
  - Make sure blast machine is adequately grounded.
8. Do not weld on blast machine, this voids approval.
9. Do not substitute Airblast parts or modified equipment in any way.



## AIRBLAST B.V.

P.O. Box 1075  
1700 BB Heerhugowaard  
The Netherlands  
Tel. : + 31-72-5718002  
Fax : + 31-72-5714340  
E-mail : [info@airblast.com](mailto:info@airblast.com)  
Web : [www.airblast.com](http://www.airblast.com)

# SINGLE CHAMBER BLAST MACHINES

## ABSC-1440 / 1648 / 2048 / 2452 / 2460

**1.0 INTRODUCTION:** This manual covers the set-up, maintenance of the following pressure type of blast machines.

| AIRBLAST model | CAPACITY |      |
|----------------|----------|------|
|                | ltr.     | lbs. |
| ABSC-1440      | 60       | 180  |
| ABSC-1648      | 100      | 300  |
| ABSC-2048      | 140      | 420  |
| ABSC-2452      | 200      | 600  |
| ABSC-2460      | 300      | 900  |

See page 4 for all basic components of the ABSC-Model single chamber blast machines.

## 2.0 OPERATION SET-UP

### 2.1 Set-up

The set-up procedure for manual controlled blasting (without the use of a remote control system) is as follows:

- Make sure that the compressor is located upwind from the blasting area. Start the compressor and bring it up to operating pressure and temperature before beginning the blast cleaning operation.
- Open the bleed-off and choke valves (handles in parallel position with piping).
- Close the air inlet valve at the abrasive valve.  
Closed valves:
  - sand valve : extreme position of handle to either side of the center of the valve.
  - grit valve : full clockwise position of the handle.
- Connect the compressed air line to the air inlet valve (minimum 1¼" ID air line for optimum blast cleaning performance).
- Connect the blast hose quick connect coupling to the machine quick coupling. Check condition and proper placing of the rubber coupling gaskets.
- Fill the concave head of the machine with abrasive. The abrasive will pass the filling port into the machine.
- Put on all protective clothing.

**2.2 Operation:** To blast clean, the machine tender:

- Puts pressure to the air line of the blast machine.
- Closes the bleed-off valve.
- Opens the air inlet valve, when the blasting operator signals that he is ready. This causes sealing of the filling port by the pop-up valve and the blast machine will pressurize. Only air will come out of the nozzle.
- Adjusts the abrasive valve for proper air/abrasive mixture. **General rule:** use as little abrasive as possible. The abrasive stream coming out of the blast nozzle should hardly discolor the air when seen against whatever light source.
- Closes the air inlet valve and quickly opens the bleed-off valve to stop blasting.

### 2.3 Shut-down

When shutting down for the day: empty the blast machine of all abrasive by removing the nozzle and putting the blast hose in a suitable waste container. Close the choke valve and put the handle of the abrasive valve in full open position. Then put pressure to the machine by opening the air inlet valve.

The blast machine should be covered if left out at site, in order to prevent moist abrasive to cause trouble when starting up blasting again.

**USE ONLY ABRASIVE SPECIFICALLY MEANT FOR BLASTING, NEVER USE UNSCREENED OR MOIST ABRASIVES.**

## 3.0 MAINTENANCE

### 3.1 Replacement of the Pop-up valve

Remove the inspection door assembly in order to get access to the Pop-up valve. Unscrew the Pop-up guide (page 2, item 20) by counter-clockwise turning. Remove both Pop-up valve and guide from the blast machine. Put the new Pop-up valve in the valve guide and then install them inside of the machine.

It is recommended to replace the inspection door gasket at the same time. Do not forget to tighten the inspection door assembly back onto the machine.

### 3.2 Replacement of the Pop-up O-ring

# SINGLE CHAMBER BLAST MACHINES

## ABSC-1440 / 1648 / 2048 / 2452 / 2460

Put your fingers between the Pop-up O-ring and the retainer and slowly remove the old O-ring. If necessary, use a screwdriver. Push the new Pop-up O-ring through the filling port and fit it into the retainer. Pull up on the O-ring in order to get it into position.

### 4.0 TROUBLESHOOTING

#### 4.1 Blockages

If neither abrasives nor air comes out of the blast nozzle, first depressurize the machine and then check if the nozzle is clogged. If only air comes out and no abrasive, fully open the abrasive valve and then quickly open and close the choke valve. If this fails, depressurize the machine, remove the inspection door assembly and check the inside of the machine for foreign objects (paper, etc.).

#### 4.2 Abrasive surge

When starting up, surge of abrasive is normal


to some extent. However, if the abrasive surge should continue, the flow of abrasive can usually be stabilized by the quick opening and closing of the choke valve.

An intermittent abrasive flow is sometimes caused by an excess of moisture in the blasting system. This problem in practice can be solved by installing a moisture/water separator in the air line, closest to the machine as possible.

#### 4.3 Removal of moist abrasive


In order to remove moist abrasive from the system, the blast hose has to be disconnected and the rubber gasket in the quick coupling on the machine has to be removed. The next step is to close the choke valve and open the abrasive valve. Force out any moist abrasive by pressurizing the machine.

See separate Instruction-Parts List for Remote Control Systems.



# SINGLE CHAMBER BLAST MACHINES

## ABSC-1440 / 1648 / 2048 / 2452 / 2460



**SINGLE CHAMBER BLAST MACHINES**  
**ABSC-1440 / 1648 / 2048 / 2452 / 2460**

**5.0 SPARE PARTS**

| ART.NR. | MODEL | DESCRIPTION                                      |     |     |     |     |
|---------|-------|--|-----|-----|-----|-----|
| 01)     | 21996 | Elbow 1¼"  | FM  | no. | 92  | (1) |
| 02)     | 22116 | T-piece 1¼"                                      | FFF | no. | 130 | (1) |
| 03)     | 22256 | Hex nipple 1¼"                                   | MM  | no. | 280 | (4) |
| 04)     | 11930 | Air valve 1¼"                                    |     |     |     | (2) |
| 05)     | 22496 | Union 1¼"  | FM  | no. | 341 | (2) |
| 06)     | 10340 | Pipe 1¼" for 2452 (200 L)                        |     |     |     | (1) |
|         | 10350 | Pipe 1¼" for 1440 (60 L)                         |     |     |     | (1) |
|         | 10360 | Pipe 1¼" for 1648 (100 L)                        |     |     |     | (1) |
|         | 10370 | Pipe 1¼" for 2048 (140 L)                        |     |     |     | (1) |
| 07)     | 21936 | Elbow 1¼"  | FM  | no. | 41  | (1) |
| 08)     | 13390 | Pipe 1¼" for 2452 (200 L)                        |     |     |     | (1) |
|         | 13400 | Pipe 1¼" for 1440 (60 L)                         |     |     |     | (1) |
|         | 13405 | Pipe 1¼" for 1648 (100 L)                        |     |     |     | (1) |
|         | 13410 | Pipe 1¼" for 2048 (140 L)                        |     |     |     | (1) |
| 09)     | 21916 | Elbow 1¼"  | FM  | no. | 40  | (1) |
| 10)     | 60010 | Abrasive valve 1¼"                               |     |     |     | (1) |
| 11)     | 10460 | Pipe 1¼" x 100 mm rubber lined                   |     |     |     | (1) |
| 12)     | 10440 | Y-piece 1¼" rubber lined                         |     |     |     | (1) |
| 13)     | 21630 | Coupling 1¼" incl. gasket                        |     |     |     | (2) |
| 14)     | 10650 | Wheel required for 1440 (60 L)                   |     |     |     | (2) |
|         | 10660 | Wheel required for 1648 (100 L)                  |     |     |     | (2) |
|         | 10670 | Wheel required for 2048 (140 L)                  |     |     |     | (2) |
|         | 10680 | Wheel required for 2452 (200 L) and 2460 (300 L) |     |     |     | (2) |
| 15)     | 10450 | Hex nipple 1¼" rubber lined                      |     |     |     | (2) |
| 16)     | 22596 | Elbow 1¼" x 1"                                   | FF  | no. | 90  | (1) |
| 17)     | 10270 | Inner pipe 1¼" for 2452 (200 L) and 2460 (300 L) |     |     |     | (1) |
|         | 10280 | Inner pipe 1¼" for 1440 (60 L)                   |     |     |     | (1) |
|         | 10290 | Inner pipe 1¼" for 1648 (100 L)                  |     |     |     | (1) |
|         | 10300 | Inner pipe 1¼" for 2048 (140 L)                  |     |     |     | (1) |
| 18)     | 11920 | Pop-up O-ring                                    |     |     |     | (1) |
| 19)     | 11880 | Pop-up valve with shaft, flat                    |     |     |     | (1) |
|         | 11881 | Pop-up valve with shaft, round                   |     |     |     | (1) |
|         | 11890 | Pop-up valve only, flat                          |     |     |     | (1) |
|         | 11891 | Pop-up valve only, round                         |     |     |     | (1) |
|         | 11900 | Washer 21 mm                                     |     |     |     | (1) |
|         | 11910 | Pipe ½" x 165 mm                                 |     |     |     | (1) |
| 20)     | 10500 | Pipe 1" for 2048 (140 L) and 2452 (200 L)        |     |     |     | (1) |
|         | 10510 | Pipe 1" for 1440 (60 L)                          |     |     |     | (1) |
|         | 10520 | Pipe 1" for 1648 (100 L)                         |     |     |     | (1) |
| 21)     | 10470 | Inspection door gasket                           |     |     |     | (1) |
| 22)     | 10480 | Inspection door assy                             |     |     |     | (1) |
| 23)     | 10570 | Cover for 1440 (60 L)                            |     |     |     | (1) |
|         | 10580 | Cover for 1648 (100 L)                           |     |     |     | (1) |
|         | 10590 | Cover for 2452 (200 L) and 2460 (300 L)          |     |     |     | (1) |
|         | 10600 | Cover for 2048 (140 L)                           |     |     |     | (1) |
| 24)     | 10530 | Screen for 1440 (60 L)                           |     |     |     | (1) |
|         | 10540 | Screen for 1648 (100 L)                          |     |     |     | (1) |
|         | 10550 | Screen for 2452 (200 L) and 2460 (300 L)         |     |     |     | (1) |
|         | 10560 | Screen for 2048 (140 L)                          |     |     |     | (1) |
| 25)     | 21995 | Elbow 1"   | FM  | no. | 92  | (2) |
| 26)     | 11130 | Air valve 1"                                     |     |     |     | (1) |
| 27)     | 22255 | Hex nipple 1"                                    | MM  | no. | 280 | (1) |
| 28)     | 21650 | Rubber coupling gasket                           |     |     |     | (2) |

**All parts required in quantities shown ( )**


# SINGLE CHAMBER BLAST MACHINES

## ABSC-1440 / 1648 / 2048 / 2452 / 2460

### 6.0 SPARE PARTS

| ART.NR    | MODEL  | DESCRIPTION                      |     |
|-----------|--------|----------------------------------|-----|
| 60010     | FSV    | 1¼" Flat sand valve              |     |
| 01) 60020 |        | Bolt M12 x 45 mm                 | (4) |
| 02) 60030 | FSV-1  | Upper body                       | (1) |
| 03) 60040 | FSV-5  | Rubber gasket                    | (2) |
| 04) 60050 | FSV-4  | Valve                            | (1) |
| 05) 60060 | FSV-6  | Disc                             | (1) |
| 06) 60070 | FSV-7  | Lower body                       | (1) |
| 07) 60080 |        | Nut M12                          | (8) |
| 08) 60090 | FSV-10 | Head cap screw M6 x 25 mm        | (1) |
| 09) 60100 | FSV-12 | Handle bolt spacer               | (1) |
| 10) 60110 |        | Washer 6 mm                      | (2) |
| 11) 60120 |        | Wing nut M6                      | (1) |
| 12) 60130 | FSV-14 | Gauge unit                       | (1) |
| 13) 60140 |        | Set screw M6                     | (2) |
| 14) 60150 | FSV-13 | Handle pin                       | (1) |
| 15) 60160 | FSV-9  | Control handle                   | (1) |
| 16) 60170 | FSV-16 | Compressing spring               | (1) |
| 17) 60180 | FSV-18 | Packing gland (brass)            | (1) |
| 18) 60190 | FSV-19 | Packing                          | (1) |
| 19) 60200 | FSV-20 | Gasket                           | (1) |
| 20) 60210 | FSV-23 | Inspection plate bolt M8 x 35 mm | (2) |
| 21) 60220 | FSV-21 | O-ring                           | (1) |
| 22) 60230 | FSV-22 | Inspection plate                 | (1) |
| 23) 60240 | FSV-24 | Wing nut M8                      | (2) |
| 24) 60250 | FSV-17 | FSV bolt                         | (2) |

All parts required in quantities shown ( )





## **Airblast Group**

### **Airblast B.V.**

P.O. Box 1075  
1700 BB Heerhugowaard  
The Netherlands  
Tel. : + 31 72 5718002  
Fax : + 31 72 5714340  
E-mail: info@airblast.com  
Web : www.airblast.com

### **Airblast Middle East L.L.C.**

P.O. Box 33419  
Dubai  
United Arab Emirates  
Tel. : + 971 4 3242776  
Fax : + 971 4 3242778  
E-mail: airblast@emirates.net.ae

### **Airblast Saudi Arabia**

P.O. Box 30476  
Al-Khobar 31952  
Kingdom of Saudi Arabia  
Tel. : + 966 3 8473178  
Fax : + 966 3 8471430  
E-mail: info@airblast.com.sa

### **Asia Airblast Pte Ltd.**

56, Tech Park Crescent  
Tuas Tech Park  
Singapore 638085  
Tel. : + 65 6266 6010  
Fax : + 65 6266 6968  
E-mail: airblastsg@singnet.com.sg

### **AB Corrosion Control Equipment Sdn Bhd**

No. 33, Jalan Permas 3/18  
Bandar Baru Permas Jaya  
81750 Masai, Johor Darul Takzim  
Malaysia  
Tel. : + 60 7357 7989  
Fax : + 60 7357 7689  
E-mail: airblastmy@airblastasia.org